

Chiro-Flex Base

Assembly Instructions



Components:

1 x Head end
1 x Foot end
2 x Side rails
1 x Centre rail
2 x Centre legs
4 x Bed legs
26 x flexi-slats
13 x Inner slat boots
26 x Outer slat boots

Fittings:

16 x 30mm Bolts
4 x 50mm Bolts
8 x Spring washers
8 x Flat washers
4 x Headboard bolts


Tools:

1 x Allen key
1 x Spanner

Step 1 Bolt the bed legs onto the bottom of the head and foot ends using 50mm bolts with a spring washer and flat washer on each.


Step 2 Screw 2 x 30mm bolts into each side of the head and foot ends where the side rails attach leaving them loose with a 5mm gap.

Step 3 Slot the side rail end brackets over the head and foot end bolts and tighten.



Step 4 Bolt the centre legs to the centre rail with 4 x 30mm bolts with a spring washer and a flat washer on each insuring that the inner slat boot mounting holes face upwards.


Step 5 Bolt the centre rail in place using 4 x 30mm bolts and adjust the centre leg feet down to contact the floor.



Step 6 Push 13 x inner slat boots into the mounting holes in the centre rail.

Step 7 Push 26 x outer slat boots onto one end of each of the flexi-slats insuring that the mounting pins face down and the curved side of the slat faces up.

Step 8 Push the free end of each flexi-slat into the inner slat boot on the centre rail then push the outer slat boot ends into the mounting holes on the side rail.



* If fitting a headboard, bolt it to the head end using 2 or 4 headboard bolts.